




## Cable Exit Positions for 5 & 7 Pin Din (Midi) Plugs



Factory position can be changed by unscrewing the shell and Carefully rotating the pin housing

